






# STIRLING Z TENT SETUP

- A1# \*2
- A2# \*3
- A3# \*2
- B2# \*6
- B3# \*1
- C2# \*3
- D3# \*8
- E1# \*2
- E3# \*2
- F1# \*2
- F2# \*6







- Main Tent
- Ensuite
- Kids Room (Optional)
- Annexe




## Main Tent - Bow poles not shown

- NO# 13  x 1
- NO# D3  x 4
- NO# E1  x 2

## Awning One

- NO# C2  x 3
- NO# B2  x 2
- NO# E3  x 2
- NO# D3  x 4
- NO# A3  x 2
- NO# B3  x 1

## Ensuite



- NO# B2  x 2
- NO# A2  x 1

## Kids Room ( Optional Extra )



- NO# B2  x 2

Please note: Kids Room is not included in the standard package. It must be optioned in if required. Speak to your sales rep for pricing & availability.

## Window Cover type 1 (makes 1)

- NO# F1  x 2
- NO# A2  x 1

## Window Cover type 1 (makes 3)

- NO# F2  x 6
- NO# A1  x 3



## Ezy Hint

Prior to embarking on your first camping trip make sure you weather your canvas by wetting it down with a hose & letting it dry out atleast 2 times.