



STIRLING LX MK3 TENT SETUP



Main Tent - Bow Poles not shown				
NO# 4		x1	NO# D3	x4
NO# D1		x2	NO# E1	x2
Awning One				
NO# A2		x2	NO# B4	x1
NO# A3		x1	NO# C1	x3
NO# A4		x1	NO# D2	x1
NO# B1		x1	NO# D3	x4
NO# B2		x2	NO# D4	x1
NO# B3		x1	NO# E3	x2
Ensuite				
NO# A2		x3	NO# B2	x2
Kids Room (optional extra)				
NO# A2		x1	NO# B2	x2
Window Cover (makes 2)		Window Cover type 1 (makes 2)		
NO# F1		x4	NO# F1	x4
NO# A2		x2	NO# A1	x2



Ezy Hint

Prior to embarking on your first camping trip make sure you weather your canvas by wetting it down with a hose & letting it dry out atleast 2 times.



Please note: Kids Room is not included in the standard package. It must be optioned in if required. Speak to your sales rep for pricing & availability.